


Narrow Band Saw











Material Restrictions

- Maximum depth of material is 200mm
- Cutting non-wood materials i.e. metal, acrylic, etc. requires a different blade to be fitted

Machine Use

- Before switching on the Narrow Bandsaw always:
 - ensure the saw blade is in tension
 - adjust the sliding guard as close as possible to the workpiece
 - ensure blade guides give support to the whole of the blade width up to the teeth gullets. blade guides do not grip the blade - set a small fraction away
 - ensure that the thrust wheel is adjusted correctly. The thrust wheel never comes into contact with a blade at rest set 0.5mm away
- Feed the stock easily let the saw do the work. If excess pressure
 is required the blade may twist or break, and there is the risk of
 your hands slipping into the moving blade
- A push-stick **MUST** be available to feed small components
- Push-sticks should be at least 450 mm long with a 'bird's mouth'
- NEVER PUT YOUR HANDS IN LINE WITH THE SAW CUT FOR ANY REASON WHILE THE MACHINE IS RUNNING

Regulations

- Adjust guard as close as possible to the workpiece surface
- The pulley wheels and the extent of the blade, other than that part
 of the blade that runs downwards between the top wheel and the
 machine table, must be enclosed
- The blade MUST be guarded by a frontal plate which is as close as is practicable to the blade and has at least one flange at right angles to the plate that extends behind the saw blade
- The narrow bandsaw saw MUST be braked and stop within 10 seconds
- If tension is relaxed -a permanent notice MUST be displayed to remind the next user to adjust the tension before starting the saw