

Version: BRS - V1.0 Copyright: Davin Larkin - 2014 © www.wwrasp.com

Licence: Creative Commons (CC BY-NC-ND 4.0)
Terms of use: www.wwrasp.com/about.html

Material Restrictions

- Minimum length of material is 800mm
- Maximum depth of material is **200mm** (Your machine may differ)

Machine Use

- Before switching on the Band Re-Saw always:
 - ensure the saw blade is in tension
 - adjust the sliding guard as low as possible
- Wait until the Band Re-saw is running at full speed before switching on the feed rollers
- This machine is for straight cutting only, no attempt should be made to use the machine for curved or scroll cutting
- All timber to be processed on this machine should have at least one straight, flat face which should be presented against the fence.
- If an operator is removing stock from the rear of the machine an extension table must be fitted with a min. length of 1200mm
- To change the speed of the feed wheels use the control knob.
 Setting 1 gives 7.5m/min(25ft/min), Setting 10 gives 30m/min(100ft/min). Setting 2 should suit most operations
- NEVER PUT YOUR HANDS ON THE MACHINE TABLE FOR ANY REASON WHILE THE MACHINE IS RUNNING

Regulations

- The pulley wheels and the extent of the blade, other than that part
 of the blade that runs downwards between the top wheel and the
 machine table, must be enclosed
- The blade MUST be guarded by a frontal plate which is as close as is practicable to the blade and has at least one flange at right angles to the plate that extends behind the saw blade
- The band re-saw **MUST** be braked and stop within 10 seconds
- Frontal guard should be no more than **20mm** from the workpiece
- The guard SHOULD NOT be adjusted whilst the saw is running
- To feed unit guard MUST remain in place at all times
- **DO NOT** leave the machine until the blade has come to a full stop

Band Re-Saw









